




Digitech XC- 5206 Wired Connections Replacement

This guide will help users to replace the wired connections from internal speakers to motherboard.

Written By: Kassidy Wyckoff



INTRODUCTION

This guide will help users to replace the wired connections from the internal speakers to motherboard on the Digitech XC-5206 Bluetooth speaker. Please refer to [troubleshooting page](#) before beginning replacement guide steps.



TOOLS:

- [Soldering Iron](#) (1)
- [Phillips #0 Screwdriver](#) (1)

PH2

- [Spudger](#) (1)
 - [Utility Scissors](#) (1)
-

Step 1 — Wired Connections




- Remove front panel by forcefully placing the flat edge of the spudger in between panel and plastic. Angle spudger and use fingers to pry panel off. You may need to use extra force.

Step 2




- Unscrew all eight 14mm screws closest to the edges of the speaker by spinning a size PH2 screwdriver in a counterclockwise motion.
- Dislodge face by holding speaker face down. Gently shake or tap front against table to fully remove face.
- OR grab ahold of the silver tab to pull the speaker face out. This may require force.

Step 3




- Cut zip-ties wrapped around red and green wires using scissors or pliers.

Step 4



- Pull wires out of ports using blunt nose tweezers.

Step 5



- Remove green (left) and red (right) wired connection to speaker bulb using soldering station.

To reassemble your device, follow these instructions in reverse order.