

LG G3 Earpiece Replacement

Use this guide to replace the earpiece speaker...

Written By: Dominik Schnabelrauch



INTRODUCTION

Use this guide to replace the earpiece speaker in the LG G3 (D855).

TOOLS:

PARTS:

Spudger (1) iFixit Opening Picks (Set of 6) (1) Phillips #00 Screwdriver (1) iFixit Opening Tool (1) LG G3 Earpiece Speaker (1)

Step 1 — Back Cover



- (i) Power off your phone before beginning disassembly.
- Insert a thumbnail, or a prying tool like a spudger, into the notch at the bottom left of the back cover.
- Pry the back cover up to separate its plastic clips.





- Lift the back cover to release the rest of the plastic clips and remove it.
 - (i) In case you can't lift the back cover completely, slide your fingernail or your prying tool around the midframe to release the remaining clips.
- To reinstall the back cover, press it firmly into place until you hear a snap from the plastic clips to form a seamless connection with the rear side of the phone.

Step 3 — Battery





• Use a fingernail or a prying tool at the marked notch to lever the battery out of its recess.





• Lift the battery out of its recess and remove it.

Step 5 — Loudspeaker



• Remove the four Phillips #00 screws (4 mm length).



- Insert a thumbnail, or a prying tool like a spudger, into the notch at the bottom left of the back cover you used earlier to remove the back cover.
- Pry up the plastic panel, including the loudspeaker, until you can get a good grip.

Step 7



• Carefully remove the plastic panel including the loudspeaker by gently pulling it away from the phone assembly.

Step 8 — Motherboard Cover Assembly



 Remove the eight Phillips #00 screws (4 mm length).

Step 9








- Insert an opening pick between the bottom right corner of the motherboard cover and the motherboard.
- Pry up the motherboard cover to open the plastic clips which hold the cover in its place.
 - (i) The clips can be a bit resistive. If you're having trouble prying up the motherboard cover, slightly rotate the opening pick sideways to make the process easier.
- Work your way along the right edge.








- Carefully lift the right edge of the motherboard cover.
- (i) The remaining plastic clips should open during this process or can be unhinged easily by hand.
- Remove the motherboard assembly.

Step 11 — Motherboard






• Use a spudger to pry up and disconnect the display flex cable.




• Use a spudger to pry up and disconnect the digitizer flex cable.

Step 13




• Use a spudger to pry up and disconnect the rear camera flex cable.




• Use a spudger to pry up and disconnect the front camera flex cable.

Step 15




⚠ During these next few steps, make sure to avoid damaging the flex cables you disconnected.

• Slide an opening pick under the bottom right corner of the motherboard and slowly pry it out of its recess by rotating the opening pick sideways.




• Slide the opening pick under the right edge of the motherboard where the SIM card slot is located and pry it up by rotating the opening pick sideways.

Step 17



• Grab the top section of the motherboard and carefully lift it out of the phone.

Step 18 — Earpiece speaker





⚠ During removal of the earpiece speaker, remove it together with the foam gasket underneath.

• Use a pair of <u>tweezers</u> to remove the earpiece speaker.

If possible, turn on your device and test your repair before installing new adhesive and resealing.

Take your e-waste to an R2 or e-Stewards certified recycler.

Repair didn't go as planned? Try some <u>basic troubleshooting</u>, or ask our <u>Answers</u> <u>Community</u> for help.