



# Canon Powershot SD750 Battery Replacement

To change the Canon PowerShot SD750 battery, follow this guide.

Written By: William



## INTRODUCTION

This guide will teach you how to change the Canon PowerShot SD750 battery.

## Step 1 — Battery



- Open the latch on the bottom of the camera by applying pressure to the latch and sliding it to the right.
- Insert or remove the battery through this opening.

To reassemble your device, follow these instructions in reverse order.