


Poin2 Chromebook 11 Charging Port Replacement

When a Chromebook is plugged into an outlet...

Written By: Jesse Johnson



INTRODUCTION

When a Chromebook is plugged into an outlet with a working adapter, but the device will neither charge or power on, this is a sign that the charging port is damaged and needs to be replaced. This guide shows how to replace a defective charging port for a Poin2 Chromebook 11.

TOOLS:

iFixit Opening Tool (1)
Phillips #0 Screwdriver (1)
Spudger (1)
Tweezers (1)

Step 1 — Battery





- Power down the Poin2 Chromebook 11 and disconnect the power adapter.
- Close the Chromebook and position it with the base facing up.
- Use a #0 Phillips screwdriver to unscrew the ten 7mm screws that hold the base to the rest of the frame
 - i Poin2 Chromebook 11 does not have screws under its rubber feet at the base.








- Insert a 1cm-wide plastic opening tool between the base and top frame.
 - (i) Applying pressure up and down with the tool may be necessary. When you hear a "click," this indicates the separation of the frame.
- Pry (up and down) around the entire border of the Chromebook to separate.
- Use your hands to gently lift the base away from the frame.

Step 3







- Disconnect the white 8-wire battery connector from the motherboard using a spudger to push the two L-shaped clips out of the port.
 - i The connector is a tight fit and requires careful pressure for release.



• Remove the six 4mm screws using a Phillips #0 screwdriver.

Step 5



• Lift the battery from the frame.

Step 6 — Charging Port






- (i) The changing port is located on the upper-right corner of the computer.
- Disconnect the charging port from the motherboard using a spudger to push the 4-wire connector out from the port.

Step 7




• Remove silver tape covering hinge.







- (i) The metal hinge at the top right corner must be lifted to access the charging port.
- Use a Phillips #0 screwdriver and remove the two 7mm screws from the hinge.

Step 9



- Pry the metal hinge up, until it sits perpendicular to the motherboard.
- i The metal hinge is a tight fit and requires careful strength when lifting.





• Use <u>tweezers</u> to gently pull the charging port out of the frame.

To reassemble your device, follow these instructions in reverse order.