Asus X751MA-DH01TQ Screen Replacement

This guide will show you how to replace the screen of the Asus X751MA-DH01TQ.

Written By: Collen Bleigh

This document was generated on 2020-11-28 07:05:34 AM (MST).

⚙ TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

Step 1 — Screen

- Turn the laptop upside down.

- Unscrew the 10 screws on the bottom of the laptop using a PH00 screwdriver bit.

Step 2

- Use a plastic opening tool to detach and take off the keyboard.

Step 3

- Remove the eight 5.5 Phillips #00 screws located at the top right and left hand side of panel.

- (i) There are four screws on each side.

Step 4

- Remove the four 4mm Phillips #00 screws on the bottom left and right of the screen.

- (i) There are two screws on each side.

   www.iFixit.com

Step 5

- Insert the plastic opening tool on the side of the screen and slide it all the way around to open the screen up.

Step 6

- Remove the cords on the left and right side of the screen.

Step 7

- Remove the eight total screws (4 on each side) that are on the side of the white part on the back of the screen.

Step 8

- Remove the two 4mm Phillips #00 screws on the top corners of the back of the screen.

- Remove the metal bars that you have just unscrewed.

Step 9

- Peel back the bronze sticker that is connecting the white border piece to the outside edge of the screen.

Step 10

- Use the plastic opening tool to pry open the white part away from the screen.

Step 11

- Pull the white part out and pull out the rest of the screen.

To reassemble your device, follow these instructions in reverse order.