

Oculus Rift CV1 Remote Button Replacement

How to replace the buttons for a Oculus Rift CV1.

Written By: Christian Perry



INTRODUCTION

The purpose of this guide is to provide information on replacing the buttons on your Oculus Rift CV1 remote. You can learn more about the Oculus Rift CV1 on the device page. You will need a Phillips #000 screwdriver for this replacement. Ensure buttons are cleaned with an electronics safe cleaner before reassembly to prevent the buttons from sticking.

TOOLS:

• Phillips #000 Screwdriver (1)

Step 1 — Battery



• Remove the back panel by firmly sliding it towards the strap.

Step 2



- Push down on the tab under the battery.
- Firmly slide the battery away from you. The battery should unlatch from its previous position.
- Once the battery is removed, release the tab.

Step 3 — Remote Button



 Remove the four 4mm Phillips #000 screws from the back of the remote.

Step 4



• Gently lift the wrist strap to split the back panel into two.

Step 5



- Gently peel off the top of the control board.
- (i) Be gentle, if the buttons fall off, try to keep them in the orientation that they were in.
- If the large black button falls off, place it back into the shell by orienting the tabs on the button to match the holes on the shell.

Step 6



• Pull the old buttons off and replace them with the new ones.

To reassemble your device, follow these instructions in reverse order.