

Palm Treo 680 Battery Replacement

This guide shows how to take out the Palm Treo...

Written By: Maiya123



INTRODUCTION

This guide shows how to take out the Palm Treo 680 battery in order to access various components.

Step 1 — Battery





 Remove the battery cover by pressing on the small rectangular button located on the back of the phone.

Step 2



• Remove the battery by pulling it out towards you.

