



Dell XPS 15 9575 Bottom Cover Replacement

This guide instructs you on how to...

Written By: Zack Homsey



INTRODUCTION

This guide instructs you on how to replace/remove the back cover of the Dell XPS 15 9575 in order to access the internal components.

Use caution when undoing the clips that hold the cover to the case so that the laptop is secure after reassembly.

TOOLS:

T5 Torx Screwdriver (1)

iFixit Opening Picks (Set of 6) (1)

Step 1 — Bottom Cover



 For your safety, please make sure the device is powered off and the A/C adapter is unplugged.

- Use your T5 Torx driver to remove all eight 3.2mm hex screws holding down the back panel.
- Wedge an opening pick between the back cover and the base of the board, then slightly lift the tool to pop the clips on the back cover off.

Step 2



⚠ Make sure all screws are removed before you lift the panel to prevent any damage from occurring.

- Remove the bottom cover from the device when all sides are free.

To reassemble your device, follow these instructions in reverse order.