



Replacing Nintendo DS Battery

Guide to removing and replacing the Nintendo DS battery

Written By: dnguye26



INTRODUCTION

This guide will walk you through removing and replacing the Nintendo DS battery.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tool](#) (1)
- [Spudger](#) (1)



PARTS:

- [Nintendo ds battery](#) (1)

Step 1 — Battery



- Remove the cartridge from the console.
- Use a Phillips #00 Screwdriver to remove the screw securing the battery door to the rear case.
- Remove the battery door.
- ⓘ In the images, it shows that the fixer is using a flathead screwdriver. This flathead screwdriver will work just like the Phillips #00 Screwdriver.

Step 2



- Use a plastic opening tool or spudger to pry out the battery from the bottom. If a plastic opening tool or spudger isn't available, your fingernails may work.

Step 3



- Remove the battery from the Nintendo DS.

Make sure to press the power button on the Nintendo DS when finished to confirm the battery is working.