



Skullcandy Crusher Wireless Ear Cushion Replacement

This guide will show you how to replace the ear cushion in a Skullcandy Crusher Wireless.

Written By: Valerii



INTRODUCTION

Use this guide to replace the ear cushion on a Skullcandy Crusher Wireless headphones.

Replacement ear cushions can be bought online or taken from another Skullcandy Crusher Wireless headphone. No additional tools are required to remove or add the ear cushion.



PARTS:

- [Skullcandy Crusher Wireless Replacement Ear Cushion](https://www.skullcandy.com/crusher-wireless-replacement-ear-cushion) (1)

<https://www.skullcandy.com/crusher-wireless-replacement-ear-cushion>

Step 1 — Ear Cushion



- Take your headphones and hold them upside down for better control with your hands.

Step 2



- Grab the ear cushion firmly between your thumb and forefinger with a tight grip.
- Pull the ear cushion away from the plastic, covering the speaker, by sliding the ear cushion down to release it.

Step 3



- Continue pulling it away from the edges of the plastic covering until the cushion is fully removed.

To reassemble your device, follow these instructions in reverse order.