![iFixit logo](X IFIXIT)

Samsung Galaxy Xcover GT-S5690 LCD Replacement

Replace the LCD in your Galaxy Xcover.

Written By: Jaime

www.iFixit.com

INTRODUCTION

Replace the LCD in your Galaxy Xcover.

TOOLS:

- Phillips #0 Screwdriver (1)
- iFixit Opening Tools (1)
- Precision Utility Knife (1)
- Flathead Screwdriver (1)

PARTS:

- samsung GT-S5690 LCD (1)

This document was generated on 2020-12-13 07:50:51 PM (MST).

www.iFixit.com

Step 1 — LCD

- Here is the Samsung Galaxy Xcover, with the LCD broken, that will be replaced.

Step 2

- The first step, is remove the battery door. It comes with a security lock, that has to be on open position. Start opening from bottom, and releasing from the side edges.

Step 3

- Remove with a flat screwdriver, the volume button and the power button
- Now, with a Phillpis Screwdriver, remove all the screws from the backcover.

Step 4

- With a flat screwdriver or plastic opener, separate the front case from the rear case. It will be easy!

Step 5

- Remove the screw on the lower zone of the main board. The screw is the same of the case, so dont worry if you mix them.

- Now, with a pliers, unplug the camera and the front speaker. Now, we are going to lift the main board, but ...

⚠ be careful, below is the LCD flex cable!

Step 6

- Remove the LCD flat cable, and then, remove the 2 screws on the sides of the front cover. They are the same as the others screws...

- Now, you can take apart the chassis from the front cover, leaving only the display and the touch.

Step 7

- Lift up the black retainer, and take off the touch flex cable.

- Be careful, the flex has double side tape below the IC.

- Now, with a knife or cutter, lift carefully the LCD unit. Place the new LCD, and reassembly the phone.

- (i) In the near future, I´ll post how to replace the touch screen!

To reassemble your device, follow these instructions in reverse order.