



iPhone 5s Battery Connector Replacement

Prerequisite to disconnect the battery.

Written By: Sam Goldheart





TOOLS:

- [Tweezers](#) (1)
- [Spudger](#) (1)
- [Phillips #000 Screwdriver](#) (1)

Step 1 — Battery Connector



- Remove the two 1.6 mm Phillips #000 screws securing the metal battery connector bracket to the logic board.

Step 2




- Remove the metal battery connector bracket from the iPhone.

Step 3



- Use the flat end of a spudger to gently pry the battery connector up from its socket on the logic board.

 Be very careful to only pry up on the battery connector and not the socket on the logic board. If you pry up on the logic board socket, you may break the connector entirely.

To reassemble your device, follow these instructions in reverse order.