




Disassembling KDDI Kyocera A5521K Camera

These instructions will demonstrate how to...

Written By: Dominic Grisafe



INTRODUCTION

These instructions will demonstrate how to remove the camera from the KDDI Kyocera A5521K.

TOOLS:


[Tweezers](#) (1)

[iFixit Opening Tool](#) (1)

[Tri-point Y0 Screwdriver](#) (1)

[Push Pin](#) (1)

Step 1 — Disassembling KDDI Kyocera A5521K Faceplate




- Pry, with a metal probe, the black covers that are located by the pivoting joints of the phone.
 - Beneath the covers are screws.

Step 2



- Remove the screws using a Y0 screwdriver.

Step 3



- Use the iPod pry tool to remove the outer screen.
 - Two screws are now visible.


⚠ Be careful not to crack the screen upon removal. It is adhered strongly to the phone.

Step 4




- Use the Y0 screwdriver to remove the screws.

Step 5




- Use the iPod pry tool to loosen the faceplate from the phone.
 - ① Slide the pry tool along the entire crease of the faceplate to completely detach it.

Step 6




- Separate the faceplate from the phone.

Step 7 — Camera



- Firmly grab the flexible circuit with [tweezers](#) to detach (or use your fingers if you can manage a firm grip).

Step 8



- Carefully pry up the camera unit with a spudger.
⚠ Be careful not to damage the camera unit.
- The camera should now be separated from the phone.

To reassemble your device, follow these instructions in reverse order.