

Dell Inspiron N5030 Battery Replacement

Replace the battery of the Dell Inspiron N5030.

Written By: Cristina



INTRODUCTION

This guide shows how to replace the battery of a Dell Inspiron N5030 if you have a dead or broken battery. No tools are required for this guide.

Step 1 — Battery





- Turn the computer over on its back so the battery compartment faces towards you.
- Place your fingers on the small buttons with arrows pointing outwards.
- Push and slide the buttons outward to unlock the battery compartment.

Step 2





- Grab the battery and pull it towards yourself.
- Remove the battery.

To reassemble your device, follow these instructions in reverse order.