



Toshiba Satellite M45 Battery Replacement

Written By: Stephen



INTRODUCTION

This guide describes how to replace the battery of the Toshiba Satellite M45 laptop.

Step 1 — Battery



⚠ Make sure device is off and power supply is disconnected.

- Flip the laptop to the bottom side.
- Locate and slide the two battery locks to disconnect the battery.
- Remove the battery by sliding it out away from the computer (horizontal with the casing).