



BLU Dash Music 4.0 Battery Replacement

This guide will provide step-by-step instructions on how to replace the battery.

Written By: Lioma Terrero Soto



**TOOLS:**

- [iFixit Opening Tools](#) (1)

**PARTS:**

- [Blu Dash 4.0 battery](#) (1)

Step 1 — Remove Back Cover



- Use the plastic opening tool or your fingernail to pry off the back cover.

Step 2 — Remove the Battery



- Use the plastic opening tool or your fingernail to pry off the battery from the top right corner.

Step 3 — Insert New Battery



- Place new battery with the correct orientation in place of the old one.

To reassemble your device, follow these instructions in reverse order.