



BLU Dash Music 4.0 SIM Card Replacement

This replacement guide will explain to you how to replace your SIM Card.

Written By: Lioma Terrero Soto



**TOOLS:**

- [iFixit Opening Tools](#) (1)

**PARTS:**

- [SIM card\(s\)](#) (1)

Step 1 — Remove Back Cover



- Use the plastic opening tool or your fingernail to pry off the back cover.

Step 2 — Remove the Battery



- Use the plastic opening tool or your fingernail to pry off the battery from the top right corner.

Step 3 — Remove the SIM Cards



- Remove the SIM card(s) by pulling them out of their slot(s).

Step 4 — Insert the New SIM Card(s)



- Insert the new SIM card(s) into the slot(s) by pushing them into place with the proper orientation.

To reassemble your device, follow these instructions in reverse order.