



DualShock 3 Rear Cover Replacement

Remove to access your controller's internals.

Written By: Andrew Bookholt



INTRODUCTION

Use this guide to remove the rear cover of a DualShock 3 controller.

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Rear Cover



- Remove the five 7.2 mm Phillips screws securing the rear cover to the controller.

Step 2



- Press on the rear cover between the analog sticks and slightly lift the lower edge of it away from the rest of the controller.

Step 3



- Push the rear cover slightly toward the top edge of the controller to clear the front edge of the #2 triggers.
- Pull the rear cover away from the rest of the controller, being careful not to pop off the #2 triggers.
- ⓘ If you happen to accidentally pop off the trigger buttons, we have a [trigger button guide](#) to reattach them.

To reassemble your device, follow these instructions in reverse order.