



# LG Motion 4G MS770 Battery Replacement

Replace the dying battery in your LG Motion.

Written By: Daniela Allbright



---

## INTRODUCTION

In order to replace the battery in your phone the only supplies needed are a plastic opening tool and a new replacement battery for your phone.



### TOOLS:

- [iFixit Opening Tools](#) (1)
-

## Step 1 — Remove the phone's back cover.



- Use a plastic opening tool to remove the back cover.

## Step 2 — Remove the battery.



- Use a plastic opening tool to remove the battery, lifting from the bottom right corner.

To reassemble your device, follow these instructions in reverse order.