



Mac Mini Late 2014 Drive Tray Assembly Replacement

Prereq to remove the hard drive and SSD tray.

Written By: Sam Goldheart



INTRODUCTION

Prerequisite only.



TOOLS:

- [T6 Torx Screwdriver](#) (1)
-

Step 1 — Drive Tray Assembly



- Remove the single 8 mm T6 screw securing the drive tray.

Step 2



- Lift the drive tray up out of the Mac mini.

To reassemble your device, follow these instructions in reverse order.