



Samsung Galaxy S5 Active SIM Card Replacement

Use this guide to remove the Sim card. You can also use this guide to remove Micro SD card.

Written By: Nils David Corrales Tovar



INTRODUCTION

The removal of the SIM card is a very simple process and tools are required to complete the objective. You can also use this guide to remove the MicroSD card. The MicroSD card would follow the same procedure as the SIM card since it goes in the slot that is just on top.



TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Rear Case



- Insert your fingernail or plastic opening tool into the divot at the top of the rear-facing camera.
- Gently pry and twist the flexible rear cover off the back of the phone.

Step 2 — SIM Card



- Use your fingers to remove the SIM card

To reassemble your device, follow these instructions in reverse order.