



# HP Pavilion zd8000 RAM Replacement

Removing the RAM from this device is...

Written By: Allie Menard



# INTRODUCTION

Removing the RAM from this device is straightforward and requires little disassembly.

---

## TOOLS:

Phillips #1 Screwdriver (1)

## PARTS:

PC2-5300 1 GB RAM Chip (1)

PC2-5300 512 MB RAM Chip (1)

---

## Step 1 — Battery



- Slide the battery release latch towards you.

## Step 2



- Pull up on the battery to remove it.

## Step 3 — RAM



- Loosen the Phillips screw labeled 'ram' and lift the cover.

## Step 4



- Locate the green RAM card and find the metal tabs securing the card.
- Push outwards on the two tabs to release the card.

## Step 5



- Carefully slide the card out at an upward angle away from the slot.

To reassemble your device, follow these instructions in reverse order.