Samsung EX2F Battery Replacement

This guide will demonstrate how to change the rechargeable battery in the Samsung EX2F digital camera.

Written By: Mohammad Haque

This document was generated on 2020-11-19 03:20:31 PM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 4

INTRODUCTION

If you are having trouble with battery life in your Samsung EX2F camera, use this guide to change your battery.

www.iFixit.com

Step 1 — Battery

- Slide the battery cover lock towards the center of the camera to unlock the battery compartment.

Step 2

- Open the battery compartment door.

- Push up on the blue battery lock tab to release the battery.

Step 3

- Remove the battery from the compartment.

To reassemble your device, follow these instructions in reverse order.