



Verizon Wireless CDM 7075 Antenna Replacement

No tools are required for this repair.

Written By: Corey Ryman



INTRODUCTION

No tools are required for this repair.

Step 1 — Antenna



- Unscrew the antenna from the top of the phone by rotating it counter-clockwise until it can be removed from the phone.

To reassemble your device, follow these directions in reverse order.