

iBook G4 12" 1.33 GHz Battery Replacement

Written By: Walter Galan



This document was generated on 2021-01-14 04:41:37 PM (MST).

INTRODUCTION

Changing the battery is easy -- all you need is a coin.

F TOOLS:	PARTS:
• Coin (1)	 iBook G3 or G4 12" Replacement Battery (New) (1)

This document was generated on 2021-01-14 04:41:37 PM (MST).

Step 1 — Battery



- Lay your iBook upside down on a flat surface.
- Use a coin to rotate the battery locking screw 90 degrees clockwise.
- Lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2021-01-14 04:41:37 PM (MST).