



Samsung Rant Keypad Replacement

Instructions for accessing and removing the keypad in the Samsung Rant cell phone.

Written By: Denise Cooper



INTRODUCTION

In order to access the keypad, you must first remove the back cover, battery and rear case from the cell phone.



TOOLS:

- [Anti-Static Project Tray](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Back Cover



- Turn the phone over in the palm of your hand, with the screen facing down.
- While grasping the bottom part of the phone with one hand, use your thumb to push the release button at the end of the phone.
- This will release the back plate latch; then lift the back plate up and out toward the other end of the phone.
- You should now be able to lift the plate completely off of the phone.

Step 2 — Battery



- Carefully remove the battery from the phone.

Step 3 — Rear Case





- Use a Phillips #00 screwdriver to loosen and remove all 3 screws.

Step 4



- Gently separate the rear case from the front case.

Step 5 — Keypad



- Using a pair of tweezers, grip the keypad gently.
- Lift the keypad out of the phone and replace it (if necessary).

To reassemble your device, follow these instructions in reverse order.