



# Dell Latitude D400 Battery Replacement

This guide will show you how to replace the battery in a Dell Latitude D400.

Written By: Lowell



## INTRODUCTION

If the battery in your Dell Latitude D400 is not working correctly, this will help you replace the battery.



## Step 1 — Pull black lever



- Used RAM stick to cover up product key.

## Step 2 — Take out battery



- Insert wisdom here.

## Step 3 — Put new battery in



- Insert wisdom here.