

Asus Zenbook UX31E Keyboard Replacement

If your Asus Zenbook UX31E laptop has stiff or...

Written By: Brian Mills



INTRODUCTION

If your Asus Zenbook UX31E laptop has stiff or unresponsive keys, use this guide to replace the keyboard.

The keyboard inputs character data to the laptop through key presses called keystrokes. Faulty keys may cause unregistered keystrokes with no input of character data. An on-screen keyboard available through Windows or an external USB keyboard may be used until internal keyboard issues are resolved.

Before starting a repair, make sure to power off your device completely and disconnect from any external power source.

TOOLS:

- T4 Torx Screwdriver (1)
- iFixit Opening Tool (1)
- Phillips #00 Screwdriver (1)
- Phillips #00 Screwdriver (1)
- Anti-Static Wrist Strap (1)
- TR7 Torx Security Screwdriver (1)

Step 1 — Back Cover



- Using a T4 Torx screwdriver, remove the ten screws at the marked locations.
- (i) Place the screws into a container as to not lose them.

Step 2



- Carefully slide your iFixit Opening Tool between the back panel.
- Lift the back plate of your ASUS ZenBook UX31E, and place it to the side.

Step 3 — Battery



• Disconnect the battery from the motherboard by gently pulling up and down on the connector.

Step 4



 Using the Phillips #00 screwdriver, remove the screws from the middle and the two corners of the battery.

(i) Place the screws into a container as to not lose them.



- Remove the battery. (Picture-1)
- Picture of what the battery looks like.(Picture-2)

Step 6 — Speaker



- Use the plastic opening tool to pry open the back cover of the laptop.
- Remove the bottom panel of the laptop.



• Remove the screw connecting the speaker component to the motherboard using the screwdriver.

Step 8



Disconnect the sound cable from the motherboard.



• Using the plastic opening tool, pry open the speaker component from the computer.

Step 10 — SSD



- Attach your Anti-Static Wrist Wrap to something metal as to not shock your system.
- Peel back the warranty sticker to reveal the screw under it.
- Using your Phillips #00 Precision
 Screwdriver, unscrew the screw that you just revealed.



• Using your hand, pull the SSD out from its slot.

Step 12 — Fan



Disconnect the ribbon between the IO and the motherboard on both sides.



- Disconnect the fan connector from the motherboard.
- Pull up the clips on the ribbon connectors.

Step 14



• Unscrew the two screws that are across each other.



- Using a plastic opening tool, lift the fan off of the laptop.
- You can now use your hands and carefully pull the fan off the laptop.

Step 16 — Motherboard



- Remove the 7 screws holding the motherboard in the case with a Phillips #00 screwdriver.
- Remove the press fit connector attaching the motherboard to the screen.
- Remove the two cables that are still attached to the motherboard. You will need to use needle nose tweezers to remove these.



- Lift gently and flip the motherboard over in the direction of the track pad.
- Peel off the the yellow tape.
- Detach the ZIF connector on the underside of the motherboard connecting it to the keyboard.
- Remove the motherboard.

Step 18 — Keyboard



• Remove the speaker assembly.

⚠ Lift gently to avoid damaging the speaker assembly.

Step 19



• Gently peel back the yellow tape to reveal where the ribbon cable attaches to the track pad.



 Remove the 56 screws marked in red circles using a Phillips #000 screwdriver.

Step 21



 Put your hand under the keyboard and gently push the keyboard up and away from the frame of the computer with your fingers.

Be very careful to not damage the keyboard itself when removing it.

To reassemble your device, follow these instructions in reverse order.