




Garmin nuvi 2460 LMT Speaker Replacement

This guide will allow you to replace a faulty or defective speaker.

Written By: Ricardo Audain





TOOLS:

- [T10 Torx Screwdriver](#) (1)
 - [Tweezers](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Back Cover



- Using a T5 Torx Screwdriver, begin unscrewing the four 11.0 mm screws from the back panel.

Step 2



- Using a plastic opening tool or similar object, find the groove in the side of the device and begin prying open the back panel. Work the tool around the entire panel until it pops off.

Step 3



- Lift the beige clamp using a tweezer or your fingernail and remove the connector.

Step 4



- Lift the connector gently from the socket, making sure you pull in the right direction.

Step 5 — Speaker



- Lift and separate the speaker connector cable using a pair of tweezers.

Step 6



- Gently lift the speaker out of the back cover using a plastic opening tool.
- ⓘ Apply force as needed if there is glue holding the speaker in place.

To reassemble your device, follow these instructions in reverse order.