



Canon PowerShot S50 Front Panel/Battery Door Replacement

Use this guide to replace the front panel of...

Written By: Karim



INTRODUCTION

Use this guide to replace the front panel of the camera as well as the battery door.

TOOLS:

Fingers (1)

Phillips #00 Screwdriver (1)

Anti-Static Project Tray (1)

Spudger (1)

Tweezers (1)

Step 1 — Battery



- Place camera LCD side up and press up on the battery door.
- Let it swing open until you can see the battery inside.

Step 2



- Press down on the orange plastic.
- This will gently eject the battery from its compartment.

Step 3



- Holding the edges, slide out the battery.

Step 4 — Front Panel/Battery Door



- Look at the camera from the side with the lanyard and 4 screws.
- Remove the two 3.4 mm screws on the metallic colored part.

Step 5



- Remove the 3mm screw on the top left.
 - ⓘ NOTE: When reassembling, it is helpful to put the top screw back in before placing the front cover back on the camera.
- Now remove the 5.3mm screw on the bottom.

Step 6



- Place the camera LCD side down.
- Remove the two 5.3mm screws by the battery door.

Step 7



- Remove the four 3.4mm screws on the bottom of the camera around the tripod mount.
- ① Make sure to keep these screws separate from the previous 5.3 mm screws.

Step 8




- Stand the camera back up.
- Remove the two 3.6mm screws on the side with the A/V Out port.

Step 9



- Lift open the rubber flap covering the A/V Out port.
- Remove the 3.4mm screw in the center.
- ⓘ During reassembly, put the A/V out rubber door on before replacing the front panel of the camera


Step 10



- Use a spudger and gently open up the front panel of the camera.


⚠ A thin plastic ribbon will stay connected by a brown piece to front panel of the camera.

Step 11




- There will be a brown plastic piece keeping the thin plastic ribbon in place.
- Use the spudger to pull out the brown plastic piece attached to the orange plastic.

Step 12



- Use a pair of [tweezers](#) and remove the metal piece inside the camera.

Step 13



- Remove the battery door
 - ⓘ NOTE: Putting this back on requires aligning the spring on the back of the door with the hole on the camera

To reassemble your device, follow these instructions in reverse order.