How to Fix a Flexi Leash

Replacing a spring inside a flexi retractable dog leash. This section prevents the tool from working.

Written By: Joanette M. Anton Cordero

INTRODUCTION

So, you've made the decision of welcoming a new member of the family. Owning a puppy is one of the greatest privilages in the world. However, raising a pup may not be the easiest job. Being in a position where almost anything is at risk of breaking, trying to fix something might seem like a good idea for that bank account. Within this guide, we will teach you how to exchange a spring that could potentially be the cause of that retractable leash to stop working. Here you see How to fix a flexi leash easily.

🔧 TOOLS:

- Phillips #0 Screwdriver (1)
- 1" Plastic Putty Knife (1)

This document was generated on 2022-07-04 12:16:14 AM (MST).

Step 1 — How to Fix a Flexi Leash

- Place the object in a clear bright space.

Step 2

- Start by removing all the 0.5 cm screws off the leash with the Phillips #0 screwdriver.

Step 3

- Using a plastic opening tool, begin to separate the top and bottom of the leash.

- ★ Make sure to press lightly to prevent unwanted marks.

- ⓘ It is most likely that the brake button will fall out. Place small items to the side to prevent it from being lost or undetected.

www.iFixit.com

Step 4

- Carefully remove the brake mechanism. Inside should be a small spring.

- Remove and replace the spring with a new one.

- ⓘ When placing the break mechanism back into its place, make sure the spring is positioned right in the middle.

Step 5

- When the spring is successfully placed, initiate the retraction to it's original position.

- Make sure the top and the bottom are aligned properly.

- Slowly press the top and the bottom of the leash until it returns to its initial position.

This document was generated on 2022-07-04 12:16:14 AM (MST).

Step 6

- Finish by screwing the 0.5 cm screws in their original position.