



# Lenovo Yoga 3 Pro Battery Replacement

This guide will show you how to access and remove the battery.

Written By: Federico LopezCasildo Jr



# INTRODUCTION

After a certain period of time or number of uses, a battery loses how long it can stay alive after a single charge. This guide shows how to replace the battery on the Lenovo Yoga 3 Pro.



## TOOLS:


- [Phillips #00 Screwdriver](#) (1)
- [T5 Torx Screwdriver](#) (1)
- [iFixit Opening Tool](#) (1)



## PARTS:

- [Lenovo Yoga Pro 3 Battery](#) (1)
- [Lenovo Yoga 3 Pro Lower Case](#) (1)

## Step 1 — Battery



**⚠** Before opening your laptop, make sure it is powered off.

- Remove the ten 3.3 mm screws from the base cover using a T5 Torx screwdriver.

## Step 2




- Slide the plastic opening tool between the base cover and the frame to pry open the computer.
- Slowly go around the entire perimeter of the computer until all edges are loose.
- i** Make sure the plastic opening tool doesn't go too far into the device.

## Step 3



- Remove the panel and place it in a safe location.


## Step 4



- Remove the six 3.5 mm screws surrounding the battery using a Phillips 00 screwdriver.




## Step 5



- Using either tweezers or your fingers, disconnect the black battery cable by pinching either side of the connector and pulling towards the battery.

## Step 6



- Carefully lift and remove the battery.

To reassemble your device, follow these instructions in reverse order.

Take your e-waste to an [R2 or e-Stewards certified recycler](#).