



Hamilton Beach 51101BA Rotor Replacement

After completing this guide you will have replaced the rotor to the blender.

Written By: Andrew Huff



INTRODUCTION

After using this guide you will have learned how to replace the rotor to your blender. You will need to use basic tools to complete this guide.

TOOLS:

- [Spudger](#) (1)
 - [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Rotor



- Remove the container from the blender.
- Hold the blender and the container, then twist the container in a clockwise motion.
- ⓘ Make sure to follow the lock and unlock markings on the container.

Step 2



- Turn the blender so the bottom is facing you.
- Using a Phillips #2 screwdriver, remove the two 5 mm Phillips screws from the base.

Step 3





- Using a Phillips #2 screwdriver, remove the two 5 mm Phillips screws from the motor platform.

Step 4



- Unhinge the plastic motor platform from the blender.
- ⓘ You may need a plastic spudger to unhinge the motor platform from the blender.

Step 5



- Using a spudger, carefully insert the tip into the coil of wire around motor.
- ⓘ This is used to hold the rotating piece of the motor still.

Step 6



- Remove the white rotor piece by rotating it counter-clockwise.
- ⓘ While rotating, make sure the rotating piece of the motor remains still.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-28 04:44:00 AM (MST).

