


PlayStation VR Headset Lenses Replacement

This guide will show you how to remove and...

Written By: Sarah Shand



INTRODUCTION

This guide will show you how to remove and replace the lenses of the PlayStation VR Headset. This can be a challenging task, but with a little patience it can be done.



iFixit Opening Tool (1)
Phillips PH000 Screwdriver (1)
Hair Dryer (1)
Tweezers (1)

Step 1 — LED Light Tracker





• Peel back the rubber covering around the lenses to remove the surrounding plastic eyepieces.



Unscrew four 13 mm screws with a PH #000 screwdriver.

Step 3




• Using the plastic opening tool, carefully pry the white plastic panel free from the side of the headset. Repeat this action for the opposite side.







- Use the plastic opening tool to pry the top white plastic panel free from the headset.
- (i) Do not try to remove the bottom plastic panel. There is a screw attaching it that must be removed first.
- (i) There may be a small amount of adhesive attaching the top panel to the headset, in which case you may need to use a bit more force to remove the panel.



- Flip the headset over.
- Using a PH #000, unscrew the 7 mm screw found on the bottom of the headset.







- Using the plastic opening tool, pry the bottom white plastic panel loose and remove it from the headset.
- (i) There is adhesive attaching the panel to the headset, in which case it will take more force to remove the panel.

Step 7








• Unscrew the two 7 mm screws from the top of the headset.








- Using your fingers, carefully pry the black front panel free from the headset.
- (i) We recommend that you start the removal from the sides by pulling them forward.
- (i) There is adhesive holding the front panel in place, which means you will need a bit of extra force to remove it.

Step 9



 Unscrew the four silver 6 mm screws in each corner using a PH #000 screwdriver.







- Lift the small silver latch attaching the ZIF (zero insertion force) connector to the circuit board.
- Carefully pull the end of the white ribbon connector from its slot.
- i Be careful not to damage or dirty the ribbon connector.






- Unhitch the yellow led connector ribbon and move it aside.
- i Be careful not to damage or dirty the ribbon connector.







- Carefully pry the black plastic piece attaching the yellow ribbon to the headset away from the green circuit board.
- Remove the yellow LED ribbons and black plastic connecting piece from the headset.

Step 13 — Headset Lenses






 Using the <u>tweezers</u>, unplug the three (one black bundled, two multi colored bundled) connector cables from their ports along the circuit board.




- Flip the headset over.
- Unscrew the two 7 mm screws near the lenses with a PH #000 screwdriver.








- Flip the headset back over.
- With your fingers, carefully pry the top black plastic panel free.




- Unscrew one silver 4 mm screw from the white plastic band connecting the rest of the headset.
 - One 4 mm screw with a PH #000 screwdriver.
- i Even though there are two, only one of the silver screws needs to be unscrewed.

Step 17





• Move the top black wires aside.







- Using a finger, press the black plastic tab up to loosen the white connector piece.
- Slide the white plastic connector piece back and lift up to remove it.



- Unscrew the five silver 6 mm screws from the circuit board.
 - Five 6 mm scews with a PH #000 screwdriver.





- Using your fingers, lift up on the sides of the black plastic piece holding the circuit board in place.
- There are small plastic tabs on the side that latch the piece in place that need to be lifted in order to remove it.





- Carefully lift the circuit board out of the headset and set aside.
- *i* Take care not to touch the screen.





• Using a hairdryer (or heatlamp), warm the area around the lenses. This will help loosen them for removal.

Step 23





• Using a glass cloth (or any cloth with soft fibers), carefully press on the lenses until they pop out of place.

To reassemble your device, follow these instructions in reverse order.